


ASLINKER

B281 □ B-02U □ -CC20



■ Note on use ⇒ A separate Address Writer is required to set addresses and other data.

* For more information, refer to [Various Settings] on page 9.

[Type]

B281SB-02U-CC20	NPN input
B281XB-02U-CC20	NPN input/NPN output
B281PB-02U-CC20	NPN output

B281SB-02US-CC20	PNP input
B281XB-02US-CC20	PNP input/PNP output
B281PB-02US-CC20	PNP output

[Notes on Safety]

Precautions that must be observed in order to use this system safely are indicated as shown below. You must observe these precautions.



WARNING A WARNING indicates a potentially hazardous situation which, if not handled correctly, could result in death or serious injury.



CAUTION A CAUTION indicates a potentially hazardous situation which, if not handled correctly, may result in personal injury or property damage.



- System Safety
This system is intended for general industrial applications. It does not have functions for supporting applications requiring higher levels of safety such as safety-related devices or accident prevention systems. The product must not be used for these purposes.
- Before installation, replacement and/or cleaning of the product, be sure to turn OFF the power supply for the system.
- Prolonged continuous flow of a rated load current or higher or a transit current due to load short-circuit, etc., in the hybrid unit including the output unit and the output circuit may result in smoking or firing. An external safety device such as a fuse must be installed.



- System power supply
Use a stable, 24V DC power supply. Use of an unstable power supply may cause problems with the system.
- Separately route high-voltage and power cables
Although the AnyWireASLINK has a high noise margin, install the transmission line and I/O cables away from high-voltage and power cables.
- Connectors and terminals
 - Pay careful attention to the length and installation of cable wiring to ensure that connectors and cables are neither overloaded nor disconnected.
 - Make sure to prevent any metal objects from getting inside the connectors or the terminal blocks.
 - Short-circuits caused by metal objects or mis-wiring are likely to damage the device.
- Do not impose any external loads on the units. Doing so may cause a failure.
- Do not disconnect or reconnect between the transmission line and remote units when the transmission line is active. A malfunction may occur.
- Use the AnyWireASLINK within the range of the specifications and conditions shown below.
- The equipment is an Open-type device which is intended to be installed in a suitable external enclosure for fire, shock and mechanical protections.
- Equipment installation, wire insulations, routing and separations shall in compliance with NEC/CEC and any requirements from local authorities.

[Warranty]

■ Warranty period

The warranty on the delivered Product shall continue to be effective for one (1) year after the delivery thereof to a location as designated by the original owner.

■ Scope of warranty

Should a defect occur in any part of the Product during the foregoing warranty period when it is used normally in accordance with the specifications described in this Products Guide, the Company shall replace or repair the defect free of charge, except when it arises as a result of:

- [1] Misuse or abuse of the Product by the owner;
- [2] Fault caused by other than the delivered Product;
- [3] The unauthorized modification or repair of the Product by any person other than the Company's personnel;
- [4] Any unusual force of nature, disaster or other cause beyond the Company's control.

The term "warranty," as used herein, refers to the warranty applicable to the delivered product alone. The Company shall not be liable for consequential or incidental damages resulting from any malfunction.

■ Repair at cost

After the expiration of the warranty period, the owner shall be responsible for all costs and expenses incurred for the troubleshooting and repair of the Product. Even during the warranty term, the Company shall repair any defects arising from causes other than within the scope of the warranty as specified above, at the owner's cost.

■ Changes in the product specifications and the descriptions in the manual
The descriptions in this manual may be subject to change without notice.

[About Pictogram*1]

	Ver. 1.0*2		Compatible with Ver. 1.1*3
--	------------	--	----------------------------

*1 The pictogram may not be marked (or stuck) depending on the product.

*2 AnyWireASLINK device not compatible with Ver. 1.1 (word transmission and single unit simplified replacement functions)

Some products, not marked with the Ver. 1.1 pictogram, are compatible with the functions included in Ver. 1.1. Refer to the lot No. and the product guide for ultimate confirmation.

*3 For details of Ver. 1.1, refer to the subsequent pages.

[About AnyWireASLINK Ver. 1.1]

New functions have been added to AnyWireASLINK products in May 2019 onward. Also, for the purpose of differentiation of compatible functions, indication of product lot number (lot No.) has been changed.

Compatible functions vary depending on lot No. Please understand the following description thoroughly to use each product.

Functions added to Ver. 1.1 are as follows:

Functions available with Ver. 1.1	Word transmission*1*2
	Single unit simplified replacement*1

*1 To use these functions, the master unit compatible with each function is required.

For details, refer to this manual together with the manual for the master unit.

*2 You can use this function with the word-transmission AnyWireASLINK unit connected.

To handle word data, word address settings are required for remote units.


It depends on remote units whether word address setting is enabled or not.

[About Lot No.]

As a result of the addition of functions, indication of lot No. has been changed from 3 digits (conventional format: year and month only) to 6 digits or 7 digits.

Example:

Lot No. 19ECBNB



Alphabet	A	B	C	D	E	F	G	H	I	J	K	L
Month	1	2	3	4	5	6	7	8	9	10	11	12

“19E” means May 2019.

*3 Some products have no indication of function version.

[About Word Transmission]

The master unit compatible with the word transmission function provides areas for transmission and receiving of word data (numerical information) such as analog data and sensing level data.

Using this function enables reduction of occupancy of bit information area by word data.

To enable word transmission, it is necessary that the system should be configured only with remote units compatible with the word transmission function.

A remote unit incompatible with the word transmission function cannot be connected to the AnyWireASLINK system to conduct word transmission.


For remote units that handle word data, word address settings are required.

[About Single Unit Simplified Replacement]


During replacement of a remote unit, this function enables automatic settings of address and parameters of the existing remote unit into a new remote unit. (After replacement of the remote unit, address and parameter setting procedure using the address writer is not required.)

■ Step 1 Turn OFF the 24V DC power supply for the master unit.


■ Step 2 Disconnect a remote unit to be replaced.



■ Step 3 Connect a new remote unit.



■ Step 4 Turn ON the 24V DC power supply to the master unit.



CAUTION

- It is necessary that both the master unit and remote unit should be compatible with the single unit simplified replacement function.
- Before disconnection and connection of the remote unit, be sure to turn OFF the power supply.
- For compatibility of a remote unit with the single unit simplified replacement function, see the lot No. and the manual for the remote unit.
- When a remote unit of a new function version is replaced with that of an old function version, the single unit simplified replacement function cannot be used.
- Operation is enabled in the case where the model of the remote unit before replacement is the same as that after replacement.
- If the model of the remote unit before replacement is different from that after replacement, a model mismatching error occurs, disabling address and parameter settings.
- Operation is enabled in the case where the address of the remote unit for replacement is the factory-set address (bit address 511).
- Several remote units cannot be simultaneously replaced. For replacement of several remote units, conduct the replacement procedure for each unit one by one.
- For a remote unit incompatible with the single unit simplified replacement function, set an address and parameters by using the address writer as in the conventional manner.
- For details of the single unit simplified replacement function (limitations, conditions, etc.), refer to the manual for the master unit.

■ Identification of function version

Function version information is given on the lot label.

* The design and contents of the lot label may vary depending on the product model and lot No.

Anywire Corporation	
MODEL	_____
DATE	2019-05
Lot	19ECB(4B)
_____	_____
_____	_____
MADE IN JAPAN	

Function version:

When an equipment parameter is changed due to functional upgrading, etc., the function version will be updated (for example: A→B→C).

When a remote unit of a new function version is replaced with that of an old function version, the single unit simplified replacement function cannot be used.



[Functions]

■ Function list

Model	Specifications	Connection targets	Functions						Address			
			Bit transmission	Word transmission	Single unit simplified replacement	Remote address change	Detection of sensor cable disconnection		1024-point transmission	Bit address setting	Word address setting	
ASLINKER 2-wire (non-isolated) cable type	NPN input: 2 points, NPN output: 2 points NPN input: 1 point/output: 1 point PNP input: 2 points, PNP output: 2 points PNP input: 1 point/output: 1 point	General-purpose sensors, switches General-purpose output devices	○	○	○	○	○	2-wire type sensor	3-wire type sensor	○	○	×
								○	×			

*1 It depends on lot No. whether this function is available or not.

*2 This terminal can be used in connection to the AnyWireASLINK unit for word transmission. Note that this terminal cannot handle word data by setting a word address.

*3 To use these functions, a master unit that supports each function is required. For details, refer to the manual for the master unit together with this manual.

*4 This unit can be used in connection to the AnyWireASLINK system that provides 1024 bits.

■ Detecting functions (Status details)

Functions				
Remote unit voltage drop	Sensing level drop	I/O disconnection	I/O short-circuit	I/O power supply drop
○	×	○	○	○

[Function Compatibility by Lot No.]

This unit has undergone addition of functions and change of specifications according to version upgrading. Available functions and specifications of the unit vary depending on lot No.

Function	Lot No.
Remote address change	Available with lot No. that indicates year and month digits of "15J" or later
Single unit simplified replacement	
Word transmission ^{*5}	Available with S/W version "B" or later version (If lot No. is indicated in 3 digits (year and month only), these functions are not available.)
LED indication for single unit simplified replacement function ^{*6}	
1024-point transmission ^{*7}	

*5 This terminal can be used in connection to the AnyWireASLINK unit for word transmission. Note that this terminal cannot handle word data by setting a word address.

*6 The single unit simplified replacement function works even if the lot No. does not support the LED indication for the single unit simplified replacement function.
(When the master unit executes the single unit simplified replacement function, addresses/parameters will be written, if specified conditions are satisfied.)

*7 This unit can be used in connection to the AnyWireASLINK system that provides 1024 bits.


■ How to check

Lot No. is indicated on the lot label.

Example:

Lot No. 19ECBNB

H/W version ————
S/W version ————
Function version ————



[Notes on Use of 4-Wire (Isolated) Terminal]

If the total length of the sections where all the DP, DN, 24V, and 0V lines run in parallel in the power supply system is more than 50m, connect an ASLINK filter (Type ANF-01) or a filter manufactured by COSEL Co., Ltd. (Type EAC-06-472) in series to the 24V and 0V lines at a position where these four lines start running in parallel.

This will improve noise resistance, suppress the adverse effects of crosstalk caused by transmitted signals, and stabilize signals.

The above filters must be inserted regardless of whether power is supplied to all terminals collectively from the power supply for the master or power is supplied to each terminal individually from their local power supply.


Insert the "ASLINK filter [Type ANF-01]" regardless of installation method and distance when complying with CE Standard.

■ Filter allowable current


Product	Type	Allowable power current
ASLINK filter	ANF-01	MAX 5A/24V DC
Filter of COSEL Co., Ltd.	EAC-06-472	MAX 6A/24V DC

■ AnyWire Type: ANF-01 Connection example


① Power supply to the entire system




② Local power supply/branching



① Power supply to the entire system




② Local power supply/branching




[Name of Each Part]


■ Input




■ Output



■ Input/output mixed



* The lot label is attached to the back of the unit.



[Various Settings]


Address setting

Parameter setting

Common procedure for address writer operation

Be sure to connect to the AnyWireASLINK master unit to use.
 An address writer ARW-04 (Ver. 04-1.01 or later version) or ARW-03 (Ver. 2.10 or later version) is required for operation.
 For the details of the operating method, refer to the product guide of the address writer.

Connect this unit to the AnyWireASLINK master unit.
 Perform the setting using the address writer with the transmission signal (DP, DN) supplied.



Address setting

An address number is set as a beginning number from which part of the transmission frame is occupied to the terminal.
 Set the address number within the range of bit address "0 to 254."
 (For the input/output mixed type, the same address number should be assigned to both input and output.)

- Set the address number so that the area occupied by the terminal does not exceed the transmission points of the master unit.
- Make sure that the address number setting is not duplicated.
- Also, use the address writer to read an address number that has been written in the terminal.

CAUTION

The factory-set address is "bit address 255" or "bit address 511," which indicates that an address has not been set.

The factory-set address varies depending on lot No., as follows:

For S/W version "B" or later version: Bit address 511

For S/W version "A" or 3-digit lot No.: Bit address 255

Input and output operations are disabled with the factory-set address.

Example:

Lot No. 19ECBNB

└ S/W version

Parameter setting

■ Disconnection monitoring function setting [Equipment parameter 1]

This parameter is used to specify whether the I/O cable disconnection detecting function is enabled or disabled.

Variable	Description
0	I/O disconnection detection and short-circuit detection are disabled.
1	I/O disconnection detection and short-circuit detection are enabled.

Factory setting: 0

■ Operation modes available with each model

Model		Detection of I/O disconnection									Short-circuit detection		
		2-wire type sensor			3-wire type sensor			Load			Power supply	Load	
		0VL	IN	24VL	0VL	IN	24VL	0VL	OUT	24VL	0VL-24VL	0VL-OUT	OUT-24VL
B281SB-02U-CC20	NPN	○	○	—	○	×	○	—	—	—	○	—	—
B281PB-02U-CC20		—	—	—	—	—	—	○	○	—	—	○	○
B281XB-02U-CC20		○	○	—	○	×	○	—	○	○	○	—	○
B281SB-02US-CC20	PNP	—	○	○	○	×	○	—	—	—	○	—	—
B281PB-02US-CC20		—	—	—	—	—	—	○	○	—	—	○	—
B281XB-02US-CC20		—	○	○	○	×	○	○	○	—	○	○	—

I/O disconnection detecting current

Input: When sensor's circuit current is 0.35mA or less, it is judged as disconnection.

Output: When load current in output-ON status is 2mA or less, it is judged as disconnection.

[Data Configuration]

*n = Bit address number assigned to this unit

B281SB-02U-CC20, B281SB-02US-CC20

Address offset	n+1	n
Bit input	IN1	IN0

B281PB-02U-CC20, B281PB-02US-CC20

Address offset	n+1	n
Bit output	OUT1	OUT0

B281XB-02U-CC20, B281XB-02US-CC20

Address offset	n
Bit input	IN0
Bit output	OUT0

■ Status details

The contents of an alarm detected with this unit can be checked with the "status detail area^{*1}" on the master unit.

A bit corresponding to the status detail area turns ON depending on the contents of the alarm.

Status detail area of the master unit

Status details	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
----------------	-----	-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----	----














b0: Remote unit voltage drop (DP-DN-side voltage drop)

b2: I/O disconnection

b3: I/O short-circuit

*1 This can be used on the master unit having the status detail area. For details, refer to the manual for the master unit.

[Monitor Display]


LED name	Display status	Description
LINK (Green)	Lit 	Transmission signal error Model mismatching error*1
	Flashing 	Transmission signal received
	Unlit 	No transmission signal (disconnection and reverse connection of DP and DN lines included)
ALM (Red)	Lit 	I/O disconnection, I/O short-circuit
	Flashing 	Remote unit voltage drop Model mismatching error*1
	Unlit 	No ALM available
LINK ALM	Alternate flashing LINK  ALM 	ID duplicated*2 or ID unregistered*3
LINK ALM	LINK  ALM 	Model mismatching error*1
I/O (Orange)	Lit 	ON*4
	Unlit 	OFF
	ALM LINK I/O 	When I/O flashes in synchronization with LINK while ALM is lit, it indicates I/O disconnection.

*1 This indication appears when the use of the single unit simplified replacement function fails. (This operation occurs on the S/W version "B" or later version.)

*2 This error is detected by executing automatic address recognition with master unit.

*3 For S/W version "B" or later version: This indication appears when transmission signal and power supply are normally connected, and the unit is set to the factory-set address. For S/W version "A" or 3-digit lot No.: This condition is detected when the master unit executes automatic address recognition.

*4 This unit does not operate with the factory-set address.



[Troubleshooting]

<LINK does not flash>

Things to be checked	Remedy
Check the connection of this unit.	Disconnect this unit once, and then reconnect it.
Check conditions of the master unit and remote unit.	<ol style="list-style-type: none"> 1) If LINK on the master unit is flashing and LINK on the remote unit is lit, it is possible that the master unit has a fault or power supply (24V-0V) is directly connected to the DP-DN pins of the remote unit. * If LINK is lit while ALM is flashing, it means a failure in single unit simplified replacement. 2) If LINK on the master unit is flashing and LINK on the remote unit is unlit, it is possible that the power (24V DC) is not supplied to the master unit, there is a disconnection on the transmission line (DP, DN), or the remote unit has been damaged. 3) If LINK on the master unit is not flashing, check the power supply to the master unit. Also, since there is a possibility that some system error has occurred, refer to the user's manual of the master unit. 4) A remote unit incompatible with Ver.1.1 cannot be used in connection to the AnyWireASLINK system for word transmission. Check the setting of the master unit, and lot No. of the remote unit.

<ALM is lit>

Things to be checked	Remedy
Check the connection of I/O terminals on the remote unit.	<p>When IN flashes in synchronization with LINK while ALM is lit, the unit has I/O disconnection. If only ALM is lit, the unit has I/O short-circuit or I/O voltage drop.</p> <ol style="list-style-type: none"> 1) Make sure that the remote unit I/O line and load are normally connected. Use caution about disconnection of the wiring and insufficient screw tightening. 2) To connect a mechanical contact (relay, switch, etc.) as load, OFF signal cannot be differentiated from disconnection. In this case, set the equipment parameter for the disconnection detecting function to OFF. 3) Check wiring of the remote unit terminals to ensure that the connected load meets the power supply and output specifications of ASLINER, and adjust it as required. 4) Adjust the power supply voltage of an external power source connected to the remote unit I/O line, so that the power supply voltage does not exceed the rated voltage range (21.6V to 27.6V). Make sure that wires of the transmission line do not touch each other. Check for incorrect wiring of the terminals.

<ALM is flashing>

Things to be checked	Remedy
Check the voltage (24V DC) of external power supply to the master unit.	<p>Adjust the voltage of external power supply to the master unit so that it will be in the range from 21.6 to 27.6V. (Recommended voltage is 26.4V.) Check the total length. Review the total length and wire diameter of transmission line so that the load will not exceed the current limit supplied by the transmission line and adjust the connected load. (In the case of the wire size of 1.25mm² and total length of 50m or less, the current supplied by the transmission line is 2A.) * If ALM is flashing while LINK is lit, it means a failure in single unit simplified replacement.</p>

<LINK and ALM flashes alternately>

Things to be checked	Remedy
Check the address of the remote unit.	<p>The address of the remote unit is either unregistered or duplicated. Take the following actions. * The remote unit cannot be used with the factory-set address.</p> <ol style="list-style-type: none"> 1) Set a bit address correctly in a range of 0 to 254. 2) Check if there is a remote unit on which the indicator lamps are flashing in the same manner and reset the addresses so that they are not duplicated.

<LINK is lit and ALM is flashing: Model mismatching error (Failure in single unit simplified replacement)>



Things to be checked	Remedy
Check the connection of the remote unit.	<p>Defective connections and the like may have caused single unit simplified replacement to fail. Remove the remote unit after replacement, and make connections again. * When two or more replacement remote units are simultaneously connected, the single unit simplified replacement function does not work.</p>
Check the address of the remote unit.	<p>Check if the address of the replacement remote unit is the same as the address before shipment (a bit address of 511). * If the address of the replacement remote unit is not the same as the address before shipment, the single unit simplified replacement function does not work.</p>
Check the model of the remote unit.	<p>Check if the replacement remote unit is of the same type as that of the remote unit before the replacement.</p>
Check the lot No. of the remote unit.	<p>Check if the function version for the replacement remote unit is older than that of the remote unit before the replacement. * If the function version of the replacement remote unit is older, the single unit simplified replacement function does not work.</p>

[Configuration and Electrical Characteristics of the Input and Output Circuits]

2-wire (non-isolated) NPN input B281SB-02U-CC20 / B281XB-02U-CC20 (Input)

<Circuit conditions>

Rated input voltage: 24V DC
 Max. switching current: 3.5mA
 ON current: 2.2mA or more
 OFF current: 1mA or less
 ON voltage: 16V or more (24VL-IN)
 OFF voltage: 8V or less (24VL-IN)
 Supply current at 24VL: 50mA max. (24VL-0VL)
 (per point)




CAUTION
 Transistor output driven by another power supply cannot be connected as ASLINKER's input.

2-wire (non-isolated) NPN output B281PB-02U-CC20 / B281XB-02U-CC20 (Output)

<Circuit conditions>

Withstand voltage: 30V DC
 Max. ON current: 100mA (per point)





To connect inductive load, use a surge killer.

If output is turned ON with the 24VL and OUT terminals short-circuited, the output device will be damaged.

2-wire (non-isolated) PNP input B281SB-02US-CC20 / B281XB-02US-CC20 (Input)

<Circuit conditions>

Rated input voltage: 24V DC
 Max. switching current: 3.5mA
 ON current: 2.2mA or more
 OFF current: 1mA or less
 ON voltage: 16V or more (IN-0VL)
 OFF voltage: 8V or less (IN-0VL)
 Supply current at 24VL: 50mA max. (24VL-0VL)
 (per point)




CAUTION
 Transistor output driven by another power supply cannot be connected as ASLINKER's input.

2-wire (non-isolated) PNP output B281PB-02US-CC20 / B281XB-02US-CC20 (Output)

<Circuit conditions>

Withstand voltage: 30V DC
 Max. ON current: 100mA (per point)



To connect inductive load, use a surge killer.

If output is turned ON with the OUT and 0VL terminals short-circuited, the output device will be damaged.

[Equipment Parameter and Its Setting]

Equipment parameter	Setting item	Description	Variable	Description
1	Disconnection monitoring function setting	Used to specify whether the I/O cable disconnection detecting function is enabled or disabled. Factory setting: 0000	0000	I/O disconnection detection and short-circuit detection disabled
			0001	I/O disconnection detection and short-circuit detection enabled

[Specifications]

■ General specifications

Operating ambient temperature/humidity	0 – +55°C, 10 – 90%RH No condensation
Storing ambient temperature/humidity	-25 – +75°C, 10 – 90%RH No condensation
Vibration resistance	Based on JIS B 3502
Shock resistance	Based on JIS B 3502
Atmosphere	No corrosive gas
Operating altitude*1	0 – 2000m
Pollution level*2	2 or less

*1 Do not use or store AnyWireASLINK devices in an environment where the pressure exceeds the atmospheric pressure at an altitude of 0 meters. Doing so may result in malfunction.

*2 "Pollution level" is an index that indicates the degree of occurrence of conductive substances in the environment where the device is used.
Pollution level 2 means the occurrence of only pollution by non-conductive substances. In such an environment, however, electrical conduction could occur due to accidental condensation.

■ Transmission specifications

Service power supply voltage	24V DC +15% to -10% (21.6 to 27.6V DC) with a ripple of 0.5Vp-p or less
Transmission method	DC power supply superimposed total frame/cyclic method
Synchronization method	Frame/bit synchronization method
Transmission procedure	AnyWireASLINK protocol
Connection mode	Bus type (Multi-drop method, T-branch method, Tree branch method)
Number of connection points*3	Number of bit points: 1024 points max. (Input: 512 bits, Output: 512 bits) Number of word points: 1024 words max. (Input: 512 words, Output: 512 words)
Number of connection units*3	Up to 256 units
RAS function	Detection of transmission line disconnection, transmission line short-circuit, transmission power supply drop, and duplicated/unregistered ID

*3 The number differs depending on the master unit. Be sure to refer to the manual of the master unit for the number.


■ Specifications of the cable included in ASLINKER

Model	①Transmission side				②Input side			
	Signal name	Number of core wires	Core wire size	Core wire sheath outer diameter	Signal name	Number of core wires	Core wire size	Core wire sheath outer diameter
B281SB-02U-CC20	DP (Red) DN (Black)	2	AWG24	φ 1.5mm	IN(Black), 24VL(Brown), 0VL(Blue)	3	AWG26	φ 1.0mm
B281SB-02US-CC20					OUT(Black), 24VL(Brown)			
B281PB-02U-CC20					OUT(Black), 0VL(Blue)			
B281PB-02US-CC20	DP (Red) DN (Black)	2	AWG24	φ 1.5mm	IN(Black), 24VL(Brown), 0VL(Blue)	3	AWG26	φ 1.0mm
B281XB-02U-CC20					OUT(Black), 24VL(Brown)			
B281XB-02US-CC20					IN(Black), 24VL(Brown), 0VL(Blue) OUT(Black), 0VL(Blue)			

*The figure shows an example of B281XB.







[Outside Dimensions]

Unit: mm



* This figure shows an example of the I/O-mixed type terminal.

■ADP-81 (Mounting adaptor)



[Directive on Waste Electrical and Electronic Equipment (WEEE)]



Note: This symbol mark is for EU countries only.
This symbol mark is according to the directive 2012/19/ EU Article 14 Information for users and Annex IX.

This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste.

【中国版RoHS指令】

的产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 [Cr (VI)]	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
安装基板	×	○	○	○	○	○
框架	○	○	○	○	○	○

本表格依据 SJ/T11364 的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T26572规定的限量要求。



基于中国标准法的参考规格：GB/T15969.2

[Address]

Anywire Anywire Corporation

Headquarters :1 Babazusho, Nagaokakyo-shi, Kyoto 617-8550 JAPAN

Contact :Contact by mail info_e@anywire.jp
:Contact by website http://www.anywire.jp